







## **Room Thermostat**

in combination with Bosch Smart Home Controller II\*

Function  Set temperature  Displayed temperature (current/target)  Humidity  Operation mode (manual/schedule)  Schedule  Boost  Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios  Services	
Displayed temperature (current/target)  Humidity  Operation mode (manual/schedule)  Schedule  Boost  Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Function
Humidity Operation mode (manual/schedule) Schedule Boost Temperature adjustment Child lock Faults (battery defect, trouble, tampered) Battery status Automations/Scenarios	Set temperature
Operation mode (manual/schedule)  Schedule  Boost  Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Displayed temperature (current/target)
Schedule  Boost  Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Humidity
Boost  Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Operation mode (manual/schedule)
Temperature adjustment  Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Schedule
Child lock  Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Boost
Faults (battery defect, trouble, tampered)  Battery status  Automations/Scenarios	Temperature adjustment
Battery status Automations/Scenarios	Child lock
Automations/Scenarios	Faults (battery defect, trouble, tampered)
·	Battery status
Services	Automations/Scenarios
	Services

Bosch Smart Home System
2
• <sup>2</sup>
• <sup>2</sup>
• <sup>2</sup>
• <sup>2</sup>
2
•
•
•
• 3
•

Notice Section	
Matter System	
• 1	
● 1	
• 1	
● 1	
<b>●</b> <sup>1</sup>	
• 1	

<sup>\*</sup> A radio stick (868 MHz) is required for use.

¹ Possible use depending on the selected Matter Smart Home system.

² This function can only be used via the room temperature control. The room temperature control combines thermostats in one room to uniformly regulate the temperature in the room.

<sup>&</sup>lt;sup>3</sup> Low battery indicator in the notifications.