







## **Room Thermostat II 230 V**

in combination with Bosch Smart Home Controller II

Function
Set temperature
Displayed temperature (current/target)
Humidity
Cooling
Operation mode (manual/schedule)
Sensor connection
Sensor connection (not used / temperature sensor / potential-free contact)
Display switch-on duration (in sec)
Display brightness (in %)
Schedule
Boost
Temperature adjustment
Child lock
Valve type (normally open/normally closed)
Heater type (boiler, underfloor heating, radiator)
Test signal strength
Faults (shown in message center: battery defect, trouble, tampered)
Range extension (information)
Automations/Scenarios
Services (climate manager "sustainable ventilation", "heating break & cooling")

	© BOSCH
Device	<b>Bosch Smart Home System</b>
• <sup>2</sup>	• <sup>2</sup>
• <sup>2</sup>	• <sup>2</sup>
• <sup>2</sup>	• <sup>2</sup>
	<b>●</b> 2/3
	• <sup>2</sup>
•	
	•
	•
	•
	• <sup>2</sup>
	• <sup>2</sup>
	•
	•
	•
	•
	•
	•
	•
	•
	•

Matter System	
● 1	
● 1	
● 1	
<b>●</b> 1	

<sup>&</sup>lt;sup>1</sup> Possible use depending on the selected Matter Smart Home system.
<sup>2</sup> This function can only be used via the room temperature control. The room temperature control combines thermostats in one room to uniformly regulate the temperature in the room.
<sup>3</sup> Only in combination with a heat pump.