

Open-Source-Software

This Bosch Smart Home product uses open-source software. The license information for the components is as follows.

core_cm3.h

Copyright (C) 2009-2013 ARM Limited. All rights reserved. Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

- ▶ Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
- ▶ Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and / or other materials provided with the distribution.
- ▶ Neither the name of ARM nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS „AS IS“ AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT OWNER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Safety instructions

- ▶ Never charge the supplied batteries. Do not throw batteries into fire! Do not expose batteries to excessive heat. Do not short-circuit batteries. Danger of explosion!
 - ▶ Do not modify the product in any way. Any other use is considered unintended use. We will not assume liability for any resulting damage.
 - ▶ The product may only be used indoors with Bosch Smart Home original components and recommended partner products. Avoid dust, moisture, vibrations, constant sun or other sources of heat radiation, cold and mechanical stress.
 - ▶ When choosing a fixing location and when drilling, pay attention to potential electrical lines and / or supply lines that could be behind the wall.
 - ▶ The device is not a toy! Do not allow children to play with it. Do not leave packaging material lying around carelessly. Plastic foils and small parts can become dangerous toys for children.
- ▶ This device may be used by children aged 8 years and over, and by persons with reduced physical, sensory or mental abilities or with lack of experience and knowledge, if they have been supervised or instructed in the safe use of the device and understand the resulting hazards.

Declaration of conformity

Robert Bosch Smart Home GmbH declares that this Bosch Smart Home wireless radio equipment Room Thermostat (THB) is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

www.bosch-smarthome.com/conformity



Environmental protection and disposal

Electrical and electronic equipment that is no longer usable and defective or used batteries must be separated from other waste and recycled in an environmentally friendly manner (European Directive on waste electrical and electronic equipment). To dispose of electrical and electronic equipment or batteries, use your country-specific return and collection systems.



Technical data

Model	THB
Article number	8-750-001-259
Batteries	2x 1,5 V LR03/Micro/AAA
Radio frequency	868,3 MHz / 869,525 MHz
Max. transmission power	10 mW
Radio range in free-field conditions	Up to 100 m
Protection class	IP20
Ambient temperature	+5 °C to +35 °C



BOSCH

LET'S GET EN
STARTED




Room Thermostat

Quick start guide



LET'S GET STARTED




1. Install Smart Home Controller

If not yet installed: Download the Bosch Smart Home app and install the Bosch Smart Home Controller.




2. Start Smart Home App

Now start the Bosch Smart Home app and select "Add device". Follow the instructions in the app.




3. Scan the QR-Code

The app will prompt you to scan the QR code on the product. The QR code is on the backside of the thermostat.



4. Activate device


Insert the batteries to activate the device.



5. Mounting*

Adhere or screw the mounting plate to the required position on the wall.

* If possible, do not mount the device on an external wall, near a window, near a heat source or in a place exposed to direct or indirect sunlight.



6. Insert thermostat

Insert the room thermostat in the frame. Press the room thermostat against the mounting plate until it clicks audibly into place.

#BeSmarter

Service instructions

- ▶ If you have any questions, please contact our freephone service hotline.
- ▶ You can find more detailed information on operating, installation and maintaining the product online at:
www.bosch-smarthome.com/service



Robert Bosch Smart Home GmbH
Schockenriedstraße 17
70565 Stuttgart-Vaihingen



0808 1011 151* (United Kingdom)
1800 200 724* (Ireland)

Mon-Fri 7:00 am - 8:00 pm
Sat/Sun 8:00 am - 6:00 pm

*Freephone service



service@bosch-smarthome.com