



Door/Window Contact

in combination with Bosch Smart Home Controller II*

Function
Status open/closed
Profile (entrance door, window, balcony/terrace door, other)
Faults (battery defect, trouble, tampered)
Battery status
Automations/Scenarios
Services (alarmsystem, climate manager "sustainable ventilation")

Device

Bosch Smart Home System
•
•
•
• ¹
•
•

Matter System
• ²
• ²
• ²

* A radio stick (868 MHz) is required for use.

¹ Low battery indicator in the notifications.

² Possible use depending on the selected Matter Smart Home system.